

Factory Defaults

Factory Reset

Configures the CHS to revert all settings to factory defaults. The CHS will power off after scanning this barcode.




#FNBO0FO#

Instructions: After scanning the above barcode the scanner will power off. Turn scanner power back on. Next scan each of the below barcodes once. SOME CODES WILL NOT MAKE A NOISE WHEN SCANNED. Once the last code is scanned power off the scanner, then power it back on and reconnect it to your device via bluetooth.

Basic Keyboard Mode



Configures the barcode reader to Human Interface Device (HID).



Autodiscriminate UPC/EAN Supplementals (02h)



Decode UPC/EAN Supplemental Redundancy (Default: 7)



0



5